

Product 805003



805003 ProClip

Left mount

The ProClip is a mounting bracket for the vehicle's dashboard. Onto the ProClip you can install e.g. a holder for your mobile phone or PDA or a handsfree set etc. Safe and convenient - always within easy reach. The ProClip is car specific and easy to install. The installation is quick, no special tools or dismantle of the dashboard is required and it will not damage the interior of the vehicle. Made in black ABS plastic. Comes with detailed instructions.

EAN: 7320288050034

Item no 805003 fits:

Ford Transit 14-18 (For all countries)

Ford Transit Tourneo 14-18 (For Europe)

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Pull out the rubber sealant on the A-post slightly. Remove the adhesive tape covers on the ProClip.
 2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
 3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post.
 4. The ProClip is in place.
-