



## Product 805214



### 805214 ProClip

Left mount

The ProClip is a mounting bracket that you attach onto the vehicle's dashboard. It provides a perfect mounting platform for mobile phones, or other devices that you want to have within easy reach in the car. Safe, neat and convenient!

The ProClip has a perfect fit, it is custom made for each vehicle to ensure a secure base for installations. And the ProClip is easy to install. The bracket simply snaps into place in gaps in the dashboard, you do not need to drill holes, not use special tools or not dismantle the dashboard. Made in black ABS plastic. Comes with detailed instructions.

[View demo video](#)

EAN: 7320288052144

#### **Item no 805214 fits:**

Volkswagen Caravelle 16-18 (For Europe)

Volkswagen T6 Transporter/Pickup 16-18 (For Europe)

## INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the lower angled edge of the ProClip into the gap between the frame surrounding the air vent and the remainder of the dash.
  2. Press the lower angled edge all the way into the gap.
  3. Press the thin end of the enclosed gap opener into the upper gap between the frame surrounding the air vent and the remainder of the dash, to widen the gap. Insert the upper angled edge of the ProClip into the gap next to the gap opener. Remove the gap opener.
  4. The ProClip is in place.
-