



TOYOTA HILUX ED0000 – 2006 TO 2015

EZDown Instruction ED0001

1 Remove hinge stud

2 Replace hinge stud with EZDown stud and use washer for correct alignment

3 Remove tailgate cable stud

4 Replace tailgate cable stud with the EzDown upper stud

5 Place cable on stud with washer in order to align correctly

6

7 Place EZDown with piston rod facing down onto the upper and lower studs respectively

8 Secure Damper

Secure E-Clips to stud in order to hold EZDown in place at the upper and lower stud

9 Open and close the tailgate slowly to check alignment and that the cable does not interfere

10 Fit the warning sticker to the tailgate to ensure the tailgate does not get overloaded

WARNING
THIS TAILGATE HAS BEEN FITTED WITH THE EZDOWN PLEASE DO EXCEED 200KG STATIC WEIGHT ON THE TAILGATE

11

Please ensure that your two OEM parts are safely stored

REPEAT STEPS 1 - 9 FOR THE OTHER SIDE

NB: Locktite all fixing mounting points where applicable.

NB: When installed, please close tailgate gently to ensure that the cable is rotating properly and that there is no interference with any of the other hardware

FITTING KIT CODE	MANUFACTURER	MODEL TYPE	YEAR	STOCKIST	PRODUCT	REVISION	LABOUR TIME	DATE	PAGE
ED0050	TOYOTA	HILUX	2006 to 2015	GENERAL USE	EZDOWN	5	20min	12/07/2017	1
TORQUE-N.m		★ 27N.m±2N.m							

IMPORTANT:
 No liability will be incurred by Industrial Specialised Applications company, for injury, death, or property damage caused by a product which has been set up, operated, and/or installed contrary to EZDown installation guide/ manual, or which has been subjected to misuse, negligence, or accident, or which has been repaired or altered by anyone other than Industrial Specialised Applications, or which has been used in a manner or for a purpose for which the product was not designed.