


LE1119\_C402-C/X\_1114-V02

		Spare part number	Spare part number	Spare part number	Colours available
1	Cover				
2	Seat		32309		30, 62
3	Pod				
4	Magnet				
5	Float box/foam				
6	Float box guiding		32330		62
7	Reed switch housing WT Reed switch PCB		<i>X-model</i>		
8	Screw				
9	Washer				
10	Cap fill bottle	16848			16
11	Waterfill funnel				
12	O-ring		32315		06
13	Fill funnel elbow				
14	O-ring				
15	Wall seal	32311			
16	Wall bracket				
17	Bench				
18	Door interface				
19	Storage cover				
20	Lock plug <i>toilet produced &lt; May 2004</i>				
21	Kicking plate (4x) Kicking plate LB	32426			62
22	Clip				
23	Vent hose				
24	O-ring		32324		
25	Seal vent plate				
26	Vent plate				
27	Base				
28	Wire clip				
29	Fuse	21766			
30	Reed switch housing + PCB	32316 <i>C-model</i>	32317 <i>X-model</i>		62
31	Magnet basket				
32	Magnet				
33	Retaining plate				
34	Fill plug				
35	O-ring				
36	Screw				
37	Bushing				

		Spare part number	Spare part number	Spare part number	Colours available
38	Screw				
39	Saddle				
40	Bracket		51802		
41	Shaft				
42	Link	51806			
43	Wire harness	32319			
	Connector spare kit PCB	51808			
44	O-ring				
45	Control well				
46	Control panel		32320		30, 62
	Control PCB		<i>C-model</i>		
47	Overlay C-model	32321		32322	62
	Overlay X-model	32323		<i>X-model</i>	
48	Handle	51803			62
49	Pump	16374			
50	Flush tube				
51	O-ring		51807		62
52	Nozzle				
53	Wire harness main power				
54	Drain connector		51804		74
55	Sight glass		<i>toilets</i>		
56	Clamp		<i>produced &gt;</i>		
57	Drain tube		<i>Oct 2005</i>		
58	Plug sight tube hole <i>toilet produced &gt; Oct 2005</i>				
59	Blind plug <i>toilet produced &gt; Oct 2005</i>				
60	Water fill extension	32329			16






LE1118\_C403-L\_1114-V03

		Spare part number	Spare part number	Colours available
1	Cover			
2	Seat		32309	30, 62
3	Pod			
4	Wire harness			
5	Wall seal	32311		
6	Bracket			
7	Bench			
8	Door interface			
9	Storage cover			
10	Lock plug <i>toilet produced &lt; May 2004</i>			
11	Kicking plate (4x) Kicking plate LB	32426		62
12	Clip			
13	Vent hose			
14	O-ring		32324	
15	Seal vent plate			
16	Vent plate			
17	Base			
18	Wire clip			
19	Fuse	21766		
20	Reed switch housing HT and PCB		32317	62
21	Magnet basket			
22	Magnet			
23	Retaining plate			
24	Screw			
25	Bushing			
26	Screw			
27	Saddle			
28	Bracket		51802	
29	Shaft			
30	Link	51806		
31	Wire harness	32319		
	Connector spare kit PCB	51808		
32	O-ring			
33	Control well			
34	Relais	20106		
35	Control panel and PCB		32313	62
36	Overlay	32314		
37	Handle	51803		62

		Spare part number	Spare part number	Colours available
38	Water supply tube			
39	Clamp			
40	Electric valve	23709		
41	Hose barb		23851	
42	Hose nut			
43	Water tube			
44	Vacuum breaker	16833		
45	Flush tube			
46	O-ring			
47	Nozzle			
48	Plug sight tube hole <i>toilet produced &gt; Oct 2005</i>			
49	Blindplug <i>toilet produced &gt; Oct 2005</i>			







LE1120\_C400-WHT\_1214-V03

		Spare part number	Spare part number	Spare part number	Colours available		
1	Sliding cover	32301			06		
2	Blade opener	32300	32331 <i>Mechanism Right</i>	32332 <i>Mechanism Left</i>	16		
3	Washer						
4	Seal parker						
5	Mechanism retainer						
6	Holding tank plate						
	Left hand version					32302	06
	Right hand version	32328			06		
7	Seal mechanism	50724					
8	Lip seal	23721					
9	Seal plate						
10	Screw						06
11	Retainer	32304					
12	Magnet						
13	Float arm						
14	Blade	50731					
15	Bearing						
16	Blade arm						
17	Bushing						
18	Screw						
19	Blade driver						
20	Support track						
21	Screw						

		Spare part number	Spare part number	Spare part number	Colours available
22	Vent lid				
23	Vent lifter				
24	Vent Spring				
25	Vent pivot				
26	Vent seal		32305		
27	Float stem				
28	Float				
29	Vent actuator				
30	Pour out spout				
31	Measuring cup		32306		06
32	O-ring				
33	Handle cover				
34	Screw				
35	Handle				
36	Vent clip				
37	Vent button				
38	Vent spring		32307		16
39	Vent seal				
40	Waste-holding tank upper				
41	O-ring				
42	Wheel support bracket				
43	Pull handle				
44	Bushing (Left/Right)		51805		16
45	Spring				
46	Tank lock clip	51801			16
47	Wheel				
48	Wheel bearing right		32308		06
49	Wheel bearing left				
50	Waste-holding tank lower				
	Waste-holding tank complete		32327 <i>Right hand version</i>	32326 <i>Left hand version</i>	06

