

Product Name: Craftsman 1000R

Product Number: 14059R

Description

Rechargeable COB worklamp with 500 & 1000 lumens
 press 1st. 500 lumens
 Press 2nd 1000 lumens
 Press 3rd OFF

Specifications

Housing material	ABS & Rubber
Lens material	PC
On/off switch	On the side
Battery type	Li-ion battery 18650 type 3.7V/4000mAh.
LED	COB
Red LED	No
Colour temperature (Kelvin)	App. 6400
Colour rendering index (CRI)	>80
Output (lumens)	500 & 1000 lumens
Run time (hours) down to 10% of full lumens	1.5hrs(high) / 3.5 (low)
Run time (hours) down to 1 lumen	NA
Beam distance	NA
Max charging input	5V 2A
Charging time (hours)	App. 6 hrs.
Charging indicator	Red LED
Battery level indicator	No
Charging port	USB C
Cable for charger, 1 m (supplied in box)	USB - USB C
Interchangeable battery	No
Protection class	IK07 / IP65
Operating temperature range (Celcius)	-10- 40
Magnet	Bottom
Hook	Bottom
Declaration of conformity	Yes
Battery MSDS	Yes
Additional info	



General Information

Lamp weight (g)	331g
Lamp dimensions (cm)	8.8*8.6*5.6CM
EAN code box (1 pc)	5703296140591
EAN code inner carton = 1 display	
EAN code outer carton = 6 displays	5703296140607
Harmonized standard code	8513100000

Packaging

Description	"PRO" design printed box
Box dimensions (cm)	9.5*7*10.5
Box weight (g)	78,1 (including lamp 410g)
Carton quantity (pcs)	32PCS (outer carton)
Carton size (cm)	40.5*23.5*31.5CM (outer carton)
Carton weight (kg)	14KGS

Features

360 degrees handy worklight and 125 degrees flexible handle with ball.
 Extremely durable.
 Hook and magnet in bottom

The following Safety Instructions apply (Where relevant)

General Safety Instructions

Do not shine in eyes. Do not immerse in water or other liquids. Do not cover the lens when turned on and do not place the product with the lens/light source direct on a surface. Do not operate if the housing, wiring compartment or lens is open, missing, or damaged. Allow the product to cool down sufficiently before cleaning. Do not use cleaners that contain abrasives or solvents. Use on flat, stable surfaces. Do not operate with wet hands. Do not disassemble. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative. Clean with a dry clean cloth. Please note that lighting products generate heat – if the heat exceeds 60 degrees turn off the product.

Safety Instructions - rechargeable products

Always inspect the charging plug - it must look dry, clean and undamaged. Only use the supplied charging cable and/or charger. Do not use a modified or damaged charger. Do not try to charge the product if it looks damaged. Do not turn on when charging. Do not leave on charge for over 24 hours. Do not charge below 0°C, above 40°C or at high humidity. Do not leave the product on charge near flammable material as it can cause a fire. Never charge without supervision. Always pay extremely attention to Li-Ion batteries as they can explode; if not handled properly, the battery may cause explosion, leakage or fire. Do not expose batteries to direct sunlight. Do not disassemble or modify batteries. Do not apply strong impacts to the battery. Do not get batteries wet. Keep batteries out of reach of children and animals. Do not place batteries on top of an electromagnetic field. Do not use batteries that work for an extremely short period of time. Do not short-circuit the battery. Do not put a battery in a microwave oven, pressure container, or other such devices. Do not recharge batteries where heat can build up. If not handled properly, the battery may cause explosion, leakage, or fire.

Safety Instructions - alkaline batteries

Only use new and undamaged batteries. Remove batteries from a device that is not being used for an extended period as they can leak. Never try to charge a non-rechargeable battery.

