



KANE150



Industrial Boiler Efficiency Analyser
with direct CO2 Measurement



JUNE 2023

CONTENTS

	Page No.
1 WELCOME TO YOUR NEW ANALYSER - PLEASE READ	6
1.1 KANE150 OVERVIEW	7
2 ANALYSER LAYOUT	8
2.1 ANALYSER BACK & PROBE	8
2.2 KEYPAD & ROTARY DIAL - FROM LEFT TO RIGHT	9
2.2.1 KEYPAD	10
2.2.2 ROTARY DIAL	10
3 FIRST TIME USE - PLEASE READ	11
4 FIT, REPLACE & CHARGE BATTERIES	11
4.1 BATTERY TYPE	11
4.2 FIT OR REPLACE BATTERIES	11
4.3 UPDATE TIME AND DATE	11
4.4 CHARGE NIMH BATTERIES	12
4.5 BATTERY DISPOSAL	12
5 POWER ON & QUICK START	12
5.1 ANALYSER DISPLAY & USE	13
6 SET UP YOUR ANALYSER - ROTATE DIAL TO MENU	13
6.1 SET UP OPTIONS	13
6.2 CHANGE ANALYSER DEFAULT SETTINGS	14

7	USE YOUR ANALYSER - ROTATE DIAL FROM MENU	14
7.1	STATUS - YOUR ANALYSER SETTINGS SUMMARY	14
7.1.2	STATUS BAR INFORMATION	15
7.1.3	STATUS BAR MESSAGES	15
7.1.4	STATUS BAR SYMBOLS	16
7.1.5	STATUS BAR OPTIONS	17
7.2	CO2 / EFF - MEASURE BOILER PERFORMANCE & EFFICIENCY	18
8	SEND, PRINT OR STORE A TSET	19
8.1	ANALYSER MEMORY	19
8.2	MEMORY MENU OPTIONS	19
8.3	VIEW & MANAGE STORED LOGS	20
9	PRINTING TO INFRARED PRINTER	21
10	SAMPLE TEST REPORTS	22
11	NECESSARY REGULAR MAINTENANCE	23-25
11.1	WATER TRAP, PARTICLE & WATER STOP FILTER	23
11.2	FLUE GAS & TEMPERATURE PROBE	23
11.3	BATTERY CHARGER & BATTERIES	24
11.4	ANALYSER & PROBE LEAK TEST	25
12	COLD WEATHER PRECAUTIONS	26
13	GENERAL SAFETY	27
13.1	FLUE GASES	27
13.2	PROTECTION AGAINST ELECTRIC SHOCK	27
13.3	MEASURING FLUE GASES	27

14	MEASUREING FLUE GASES	28
15	SPECIFICATION	29
16	EU DECLARATION OF CONFORMITY	30
17	KANE CARE	31-34
18	KANE & UKAS	35
19	FLUE GAS & APPLIANCE SAMPLE PROBE OPTIONS	36
20	SPARE PARTS	37
21	THANK YOU	38

1

WELCOME TO YOUR NEW ANALYSER - PLEASE READ

Thank you for using this KANE analyser.

Please read this manual so you know how to use your analyser - Do not assume you know how to use it.

Please read section 11 - Necessary maintenance - so you know how to care for your analyser after daily use.

Please read section 13 - General Safety - as you must be trained and competent to use this product.

Please read section 15 - Specification - to confirm measurements and calculations. This manual may reference measurements and features unavailable on this model.

Please also read section 17 - KANE CARE Service & Recertification - so you know what to do when your analyser needs KANE CARE Service & Recertification.

Any questions, visit our FAQs on www.kane.co.uk, our YouTube channel, email: sales@kane.co.uk or call 0800 059 0800 / +44 1707 375550 ex UK.

1.1 KANE150 OVERVIEW

Your analyser measures:

- Carbon Dioxide (CO₂)
- Differential Temperature

Depending on configuration it also measures, calculates or performancy:

- Oxygen (O₂)
- Combustion Efficiency, Losses & Excess Air

Your analyser is supplied with:

Protective rubber sleeve with magnets for hands-free operation

Flue gas sample probe with integral temperature sensor

USB Battery charger & 3 NiMH rechargeable batteries

Low flow detection to stop the pump if water enters analyser


Large 6 line display showing data & test results - Bottom line also displays analyser status

Test reports to send to an optional infrared KANE printer or KANE LIVE App

45 log memory for Combustion reports

2 lines of 24 characters to personalise with your details

2 ANALYSER LAYOUT







2.1 ANALYSER BACK & PROBE



2.2 KEYPAD & ROTARY DIAL - FROM LEFT TO RIGHT

2.2.1 KEYPAD

SYMBOL	KEYPAD DESCRIPTION
PUMP	Press to turn pump on or off
	DATA HOLD - Short press to hold current data on screen short press option to return to readings
	NAVIGATE UP - Short press to scroll up
ENTER	ENTER - Press to select current option - also selects torch in some dial positions
	NAVIGATE DOWN - Short press to scroll down
	STORED LOG - Long press to store data
SEND	PRINT LOG - Short press to transfer a log or test - Analyser offers a destination choice



2.2.2 ROTARY DIAL

SYMBOL	ROTARY DIAL DESCRIPTION
MENU	Manage Analyser settings - See section 6
STATUS	View Analyser status - See section 7.1
CO2 / EFF	Measure Boiler Efficiency - See section 7.2

3 FIRST TIME USE - PLEASE READ

Fit and charge your analyser batteries for 8 hours - See section 4

Setup your analyser to your requirements before use - See section 6

4 FIT, REPLACE & CHANGE BATTERIES

4.1 BATTERY TYPE

Your analyser uses rechargeable Nickel Material Hydride (NiMH) batteries.- Using other battery types may void your analyser warranty.



WARNING

You can use Alkaline batteries but do not charge analyser when fitted.

Do not mix NiMH cells with different capacities or from different manufacturers - All batteries must be identical.

4.2 FIT OR REPLACE BATTERIES

Turn over analyser & remove protective rubber sleeve to find battery compartment cover on back of analyser.

Fit 3 NiMH “AA” rechargeable batteries ensuring correct battery polarity. Replace battery cover & protective rubber sleeve.

4.3 UPDATE TIME AND DATE

Reset analyser time & date after changing batteries.

NOTE: Your analyser STATUS bar displays current time, date and battery status - Time & date can only be changed when you have no stored logs in analyser memory to protect integrity of stored logs.

4.4 CHARGE NiMH BATTERIES

Your analyser uses a standard Micro USB connector - For best results power off before connecting charger.

Charging indicator illuminates then powers off when charging is complete.

First charge for 8 hours - Thereafter NiMH batteries can be topped up any time.

If batteries analyser enters low power shutdown, a 1 hour charge will provide approx. 2 hours continuous use.

4.5 BATTERY DISPOSAL

Always dispose of depleted batteries using approved disposal methods protecting the environment.

5 POWER ON & QUICK START

Your analyser has 2 power on modes:

- Auto zero calibration countdown - Use when measuring gasses
- Quick start - Use when measuring non gas parameters eg: temperature or pressure

To measure gasses, rotate dial to any position measuring gas - Your analyser automatically starts a zero calibration countdown when powered on.

Power on analyser by pressing  button for 2 seconds.

NOTE: Always power on analyser in fresh outdoor air when performing auto zero calibration countdown.

NOTE: Connect flue gas probe hose to analyser flue gas inlet and flue gas probe temperature plug to analyser flue gas temperature socket T1.

To Quick Start, rotate dial to any position not measuring gas e.g: **MENU**, **STATUS** - Your analyser automatically starts non gas measurements when powered on.

5.1 ANALYSER DISPLAY & USE

Your analyser displays 5 lines of tests & a status bar.

Display backlight illuminates for 10 seconds with each button press.

Rotate dial to the task or function you need to perform

Navigate through options and menu choices using ▲ & ▼ then **ENTER**.

Button presses are either short or long.


6 SET UP YOUR ANALYSER - ROTATE DIAL TO MENU

This section shows how to set your analyser using the rotary dial & keypad.

6.1 SET UP OPTION

Rotate dial to **MENU**

Press ▲ & ▼ to select option, then press **ENTER** when your option is between the 2 arrows on screen.




Press ▲ or ▼ to change your selected option then press **ENTER** to confirm.

To exit **MENU** rotate dial to any position - Unsaved changes will be lost.

6.2 CHANGE ANALYSER DEFAULT SETTINGS


SETTINGS	MEANING	OPTIONS / COMMENTS
TIME	SET ANALYSER TIME	Select TIME to set analyser time - Press ENTER then use ▲ or ▼ & ENTER to set correct HH:MM:SS
DATE	SET ANALYSER DATE	Select DATE to set analyser date - Press ENTER then use ▲ or ▼ & ENTER to set To set correct DD:MM:YY
HEADER	PERSONALISE ANALYSER HEADER DISPLAY & TEST REPORTS	Select HEADER to personalise 2 lines of 24 characters - Press ENTER , then select line to edit pressing ▲ or ▼ & ENTER . Use ▲ & ▼ to select correct character then press ENTER To set HEADER via KANE LIVE app, select CONTROLS on app, select ANALYSER HEADERS, select LINE to edit Select SAVE to set header
PRINTER TYPE	SELECT KANE PRINTER	Select IR PRINTER to set infrared printer - press ENTER then use ▲ or ▼ & ENTER to select KMIRP or IRP-2/3
LOGS	LOGS	View current memory usage & stored logs
EFF	EFFICENCY	Select EFF to set efficiency scale by pressing ENTER . Select NETT or GROSS using ▲ & ▼, then press ENTER to confirm Considering calculation is automatic based on selected fuel
UTIL	UTIL	Select UTIL to access utility menu - Press ENTER then ▲ or ▼ & ENTER to select from: INFO - Shows Analyser firmware, wireless firmware & date next calibration due LEAK - Performs system leak test following onscreen instructions B'LIGHT - Selects time backlight is on from 15 to 300 seconds using ▲ or ▼ & ENTER to confirm NOTE: Extending backlight time reduces analyser battery life
CODE	CODE	Password protected for authorised service agents only - Default to 000000

7 USE YOUR ANALYSER - ROTATE DIAL FROM MENU



Status bar

7.1 STATUS - YOUR ANALYSER SETTINGS SUMMARY



Current fuel selection - use status bar menu below to change fuel

Current ambient temperature

Current atmospheric pressure (mbar)

No. of days until next calibration due

Analyser Status bar - show analyser status see 7.1.2

7.1.2 STATUS BAR INFORMATION

Status bar displays MESSAGE & SYMBOLS

Status bar messages show your analyser status use ▲ or ▼ to see them when status bar is displayed.

7.1.3 STATUS BAR MESSAGES

When you select clock function




● Analyser displays current time

When you press data hold




● Display alternates between HOLD symbol & time stamp of data on hold

When analyser calibration is overdue



● Display alternates between calibration due & current time

When you delay analyser zero recalibration



● Display alternates between zero recalibration delay symbol & current time






Your analyser needs battery recharging



● Display alternates between BAT symbol & current time





7.1.4 STATUS BAR SYMBOLS

Status bar symbols also show your analyser status

- | | | |
|-------------------|---|--|
| When you see this |  | • Your analyser pump is ON |
| When you see this |  | • Your analyser pump is Off |
| When you see this |  | • Your analyser has logged / stored data |
| When you see this |  | • Your analyser is sending data to your app or printer |
| When you see this |  | • Your analyser battery charge is displayed |

7.1.5 STATUS BAR OPTIONS


Your analyser status bar also offers options based on your current task.
Use ▲ or ▼ to view

	Always available - Display current analyser status
	Always available - Displays current date.
	Always available - Displays current fuel you can change by long pressing ENTER button. Use ▲ & ▼ to choose desired fuel then ENTER.
	Available if CO2 is on current screen - Use to manually re-zero analyser. NOTE: Always re-zero in fresh outside air

7.2 CO₂ / EFF - MEASURE BOILER PERFORMANCE & EFFICIENCY

Rotate dial to **CO₂ / EFF** to view typical combustion efficiency measurements

Check flue gas probe and temperature plug are correctly connected to your analyser before taking measurements - See section 2 where to connect,.



8 SEND, PRINT OR STORE A TEST

Short press **SEND** to send a test to your optional KANE-IRP3 printer.


Long press **SEND** for 2 seconds to store a test, called log.

8.1 ANALYSER MEMORY


Your analyser stores up to 45 tests, called logs.

A logged data icon displays when your analyser stores a test - see section 7.1.4 - Status Bar Icon

To view rotate dial to **MENU** then select **LOGS** using ▲ or ▼ & **ENTER** to display.



8.2 MEMORY MENU OPTIONS



VIEW & MANAGE STORED LOGS

To view your test, select **VIEW** from **LOGS** Menu:



List of available LOGS
Navigate and selection using ▲ or ▼
& **ENTER**

SELECT LOG TYPE




View Combustion Logs



Return to previous menu

SELECT LOG STORED

After you select report type first log is displayed:



LOG Number of that type

Time & date of LOG

Measurements & calculations specific to log type

Navigation menu options

SELECT LOG OPTIONS



Print currently selected log



Navigate to next available log



Navigate to previous log



Return to main menu

9 PRINTING TO INFRARED PRINTER

To print test result or logs use optional KANE infrared printer.

Power on printer and place printer infrared receiver in line with analyser emitter

Allow 15cm gap between analyser & printer.

10 SAMPLE TEST REPORTS

Combustion

```
KANE
KANE150
SW00182 2.55

NAME
NUMBER

SERIAL NO.      931123125

DATE            18/05/23
TIME            09:21:48

-----
CAL DUE         20/03/24
-----

COMBUSTION
-----
FUEL            NAT GAS
CO O2 REF      %      3.0
CO2            %      0.11
O2             %      20.8
T1             °C     ----
Ta             °C     23.4
NETT           °C     ----
EFFnc          %      ----
LOSS           %      ----
XAIR           %      O2++

-----

CUSTOMER
.....
.
.
.....

APPLIANCE
.....
.
.
.....

REFERENCE
.....
.
.
.....
```

11**NECESSARY REGULAR MAINTENANCE**

You must perform regular, simple and necessary maintenance to ensure your analyser works correctly.

11.1**WATER TRAP, PARTICLE & WATER STOP FILTER**

Some boilers produce high water vapour volume which can affect your analyser.

Your analyser has a water trap & particle filter with a hyd filter
Located inside the particle filter connected to a red filter carrier.

You must drain the analyser water trap when you see water collecting in it.

To drain:

1. Remove red plug
2. Empty water
3. Replace red plug

You must replace the particle & water stop filters when wet or dirty or when your analyser displays LOW FLOW.

To replace:

1. Remove protective rubber sleeve and disconnect water trap
2. Remove red filter carrier with particle & water stop filter from water trap
3. Ensure water trap is completely dry
4. Attach new water stop & particle filter to red carrier
5. Insert red carrier in water trap and reconnect water trap to your analyser.

Only use these replacement parts, available from authorized service partners or www.kane.co.uk

Water trap: SM50515

Particle filter: PF400/5 5 particle filters

Water Stop filter: SM50933/5 5 water stop filters

Red filter carrier: CM50302

11.2 FLUE GAS SAMPLE & TEMPERATURE PROBE

Always hang your probe to fully drain & dry.

You must check:

1. Your flue gas & temperature probe and tubing for cracks or leaks.
2. Your flue gas temperature probe is not bent or out of shape.
3. Your analyser connectors are not bent or cracked.



WARNING

Never cool your flue gas sample probe in water or use probe shaft as a lever.

11.3 BATTERY CHARGER & BATTERIES

See section 4 - FIT, REPLACE & CHANGE BATTERIES

11.4 ANALYSER & PROBE LEAK TEST

Your analyser will perform a system integrity test to ensure no system leaks if you connect a flue gas sample probe then cover probe tip to ensure an air tight seal.



To perform, rotate dial to **MENU** then select UTIL pressing ▲ or ▼ & **ENTER**

Select LEAK pressing ▲ or ▼ & **ENTER**

Follow analyser instructions to connect and cover probe tip

Select NEXT pressing **ENTER**

Your analyser now performs a system leak test then indicates pass or fail



COLD WEATHER PRECAUTIONS

Do not leave your analyser in a cold place overnight.

Cold electronic devices suffer when taken into a warm place and condensation may form affecting analyser performance.

Sensors are affected by condensation or water - When this happens, readings may display as “-” & sensors may be permanently damaged.

If your analyser is affected by condensation or water ingress, leave running in a warm place with pump ‘ON’ sampling fresh air for up to 3 hours - Connect charger to avoid draining batteries.

If you still experience problems please contact KANE Customer Service.

WHERE TO SEND YOUR ANALYSER - See KANE CARE Section 17

Northern Customer Service
Kane International Ltd
Gibfield Park Avenue
Atherton,
Manchester
M46 0SY, UK
e: nservice@kane.co.uk
t: 0800 059 0800

Southern & International Customer Service
Kane International Ltd
Kane House, 11 Bessemer Road
Welwyn Garden City
Hertfordshire
AL7 1GF, UK
e: service@kane.co.uk
t: 0800 059 0800

Outside UK Call +44 1707 375550

13 GENERAL SAFETY



SAFETY WARNING

13.1 FLUE GASES

Your analyser extracts combustion gases that are toxic in relatively low concentrations.

These gases are exhausted from the bottom of the analyser.

This analyser must only be used in well-ventilated locations by trained and competent persons after considering all potential hazards.

Portable gas detectors should conduct “bump” tests before relying on units to verify atmospheres are free from hazards.

A “bump” test is a way to check an instrument works within acceptable limits by briefly exposing it to known gas mixtures to change output of all sensors present.

NOTE: This is different from calibration where your analyser is exposed to known gas mixtures but allowed to settle to a steady figure with readings adjusted to the gas concentration of the test gas.

13.2 PROTECTION AGAINST ELECTRIC SHOCK (IN ACCORDANCE WITHN 61010-1:2010):

This analyser is designed as Class III equipment and should only be connected to SELV circuits. The battery charger is designated as:

- Class II equipment
- Installation category II
- Pollution degree 2
- Indoor use only
- Altitude to 2000m
- Ambient temperature 0°C-40°C
- Maximum relative humidity 80% for temperatures up to 31°C decreasing linearly to 50%RH at 40°C
- Mains supply fluctuations not to exceed 10% of the nominal voltage

14 MEASURING FLUE GASES


After countdown is finished and your analyser is correctly set up, put flue probe into appliance sampling point.

Probe tip should be in flue centre - use flue probe depth stop cone to set position.

With balanced flues, ensure probe is positioned far enough into flue so no air can “back flush” into probe.

SAFETY WARNING

Ensure flue probe handle does not get hot!



Do not exceed analyser operating specifications - In particular:

- Do not exceed flue probe maximum temperature (600°C)
- Do not exceed analyser internal temperature operating range
- Do not put analyser on hot surfaces
- Do not exceed water trap levels
- Do not let analyser particle filter become dirty and blocked

Check readings are stable and within expected range.

PARAMETER	RANGE	RESOLUTION	ACCURACY
Temperature & Pressure Measurement			
Flue Temperature	0 - 600°C	0.1°C	±0.5°C
Inlet temperature (Internal Sensor)	0 - 50°C	0.1°C	±1°C
Inlet temperature (External Sensor)	0 - 600°C	0.1°C	±0.5°C
Flue Gas Measurement			
Carbon Dioxide	0 - 20%	0.1%	±0.3% Volume
Calculations			
Oxygen	0 - 21%	0.1%	±0.3% Volume
Efficiency (Net or Gross)	0 - 99.9%	0.1%	±1% of reading
Efficiency High (C)	0 - 119.9%	0.1%	±1% of reading
Excess Air	0 - 119.9%	0.1%	±0.2% of reading
Pre-programmed Fuels			
UK USA & France	Natural Gas, Propane, Butane, LPG, Light Oil, Wood Pellets		
Battery Life	>8 hours (continuous with pump on)		
Certification	The KANE150 is independently test and certified to EN50379, Parts 1-3		
Operating Conditions			
Temperatures	0 - 45°C		
Humidity	15 to 90% RH, (non-condensing)		
Power Supply	Rechargeable batteries, USB Charging		
Physical Characteristics			
Weight	Approx. 0.625g		
Dimensions	216mm x 105mm x 45mm		

16 EU DECLARATON OF CONFORMITY

This declaration of conformity is issued under the sole responsibility of the manufacturer:-

Kane International Ltd.

Kane House, 11 Bessemer Road, Welwyn Garden City, Hertfordshire, AL10 1GF, UK.

Tel: + 1707 375550

Web: www.kane.co.uk

The KANE150 is in conformity with the relevant Union harmonization legislation below:

UK Directive	
The Electromagnetic Compatibility Regulations 2016 (EMC)	
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (RoHS)	
Electrical Equipment (Safety) Regulations 2016	
EU Directive	Title
2014/30EU	Electromagnetic Compatibility (EMC)
2011/65EU	Restriction of the use of certain hazardous substances in electrical and electronic equipment (EMC)
2014/35	Low Voltage Directive (LVD)

The following harmonised standards and technical specifications have been applied:

Certification

The KANE150 is independently tested and certified to EN 50379, Parts 1 & 3

EMC

EN50270:2015

SAFETY

EN61010-1:2010

RoHS (UK & EU)

IEC62321-2:2013, IEC62321-1:2013, IEC62321-3-1:2013, IEC62321-5:2013, IEC62321-4:2013, IEC62321-7-2:2017, IEC62321-7-1:2015, IEC62321-6:2015

Signed for on behalf of:-
01. July 2022

Kane International Ltd.



Paul Morrison



Welcome to KANE CARE


17

KANE CARE is our award winning promise to never let you down or your money back

All gas analysers must be serviced and recertified every year - In some markets this is a legal requirement

KANE CARE is all inclusive and applies to any KANE analyser booked online via www.kane.co.uk & www.kanetest.ie - some exclusions apply

For Customers outside UK & Ireland who need KANE CARE email: sales@kane.co.uk



- ★ Please **register** your analyser on our website to download your instruction manual
- ★ **PLEASE READ ALL SAFETY WARNINGS IN THE MANUAL**
- ★ Use our website to manage your Analyser, buy spares & other KANE products
- ★ Find FAQs on our website or on our YouTube Channel
- ★ Got a question? Call our Customer Service Team 7am - 5pm any normal weekday 0800 059 0800

More info at: www.kane.co.uk/service-and-re-calibration

www.kane.co.uk www.kanetest.ie
www.kane.eu www.kane-care.com





KANE CARE UK & Ireland Service & Recertification

KANE CARE is our promise to never let you down or your money back

- ★ 10 Year warranty with annual Service & Recertification
- ★ Same Day Service & Recertification guaranteed
- ★ Free next day tracked delivery to KANE
- ★ Free pre 9am next day return & Saturday am
- ★ Theft protection - 50% off when replacing your stolen KANE analyser

KANE CARE applies to any KANE FGA Service & Recertification booked online via www.kane.co.uk & www.kanetest.ie - some exclusions apply

More info at: www.kane.co.uk/service-and-re-certification

KANE CARE International Service & Recertification

KANE CARE is our promise to never let you down or your money back

- ★ 10 Year warranty with annual Service & Recertification
- ★ 20 Year all inclusive pricing
- ★ Includes accessory repair or replacement as required including probe, charger, carry bag & printer
- ★ Free tracked return
- ★ Full test certification & repair report

KANE CARE International applies to any KANE Analyser Service & Recertification booked & quote confirmed via sales@kane.co.uk - some exclusions apply

More info at: www.kane.co.uk/service-and-re-certification

Customer Service

0800 059 0800

+44 1707 375550

Email: sales@kane.co.uk

www.kane.co.uk www.kanetest.ie
www.kane.eu www.kane-care.com

Follow us on...



KANE and the Kane logo (registered in the UK and elsewhere) are trademarks of Kane Group Limited, used under licence



All other marks are trademarks of their respective holders. © 2022 Kane International Limited



UK & Ireland
Same Day Despatch
KANE CARE Service & Recertification



Register your analyser on
www.kane.co.uk or
www.kanetest.ie



Book & pay to Service & Recertify
via your dashboard

Select FREEPOST for tracked
carriage - UK & Ireland mainland only



Your analyser will be despatched
the same day we receive it...
OR YOUR MONEY BACK*

*Excludes KANE-EGA, AUTO600, '9 series' analyser & UKAS certificates - Ireland 2 day turnaround




International
All Inclusive Price
KANE CARE Service & Recertification



email: sales@kane.co.uk with
analyser name & serial number

Pay our all inclusive
KANE CARE quote



Send your analyser & accessories

We will return free of charge* after
KANE CARE Service & Recertification
with 1 year warranty if under 10 years old



*Excludes local tax & duty



Welcome to KANE & UKAS



18 KANE UKAS CALIBRATION CERTIFICATES TO - ISO 17025:2017

- ★ UKAS accreditation is the highest approval standard a test & measurement can achieve - It confirms their certification laboratory operates to the highest standard of competence & impartiality
- ★ UKAS is the only recognized UK authority assessing laboratory standards & capability
- ★ KANE is the only UK Flue Gas Analyser manufacturer accredited by UKAS to ISO 17025:2017 for gas certification
- ★ KANE UKAS calibration certificates are legal documents you can submit in evidence to a UK court - they guarantee your analyser was certified to highest possible standard
- ★ Order fixed price KANE UKAS certification any time - allow 3 days turnaround when returning your analyser for KANE CARE Service & Recertification

Any question? Call 0800 059 0800 7am - 5pm any normal weekday





More info at: www.kane.co.uk/service-and-re-calibration









www.kane.co.uk www.kanetest.ie
www.kane.eu www.kane-care.com



FLUE GAS & APPLIANCE SAMPLE PROBE OPTIONS

	<p>ASP3 KIT</p>	<ul style="list-style-type: none"> • Appliance sampling probe kit - grills, gas fires & general purpose • 5mm diameter • 2.2m flexible tube • Separate handle & hose assembly
	<p>CP2</p>	<ul style="list-style-type: none"> • 240mm probe • 6mm diameter • Neoprene hose

For a full list of accessories for your analyser, please visit our online shop at www.kane.co.uk

	<p>KANE-IRP3 KANE Infra-Red Printer</p>
	<p>USB1 USB charger for KANE258, 358, 458s, 958, KANE-EGA1,2, & 3</p>
	<p>B15 4 X 2000 mAh rechargeable batteries NOTE: battery make may differ</p>
	<p>PF400/5 (pack of five) Filters for KANECO91, 100, 101, 250, 251, 255, 258, 358, 425, 450, 451plus, 452NO, 455, 456, 457, 458, 458s, 504, 958, EGA1, 2 & 3</p>
	<p>WSF1/5 (pack of five) Water Stop Filters for KANE458s & KANE958</p>
	<p>TP5 (pack of five) Thermal printer rolls for Infra-Red Printer KANE-IRP, KANE-IRP2 & KANE-IRP3</p>
	<p>SM14980 Replacement probe connector for KANE28, 358, 458s, 958, 975, 988, EGA1, 2 & 3</p>
	<p>SM50515 Replacement water trap for KANE258, 358, 458s, 958, EGA1, 2 & 3</p>

Thank you for buying this analyser.

Before use, please register on our website

www.kane.co.uk



Scan the QR code to go directly to
Register your product online.

Kane International Ltd
Kane House, 11 Bessemer Road
Welwyn Garden City
Hertfordshire
AL7 1GF, UK
email: sales@kane.co.uk
telephone: 0800 059 0800

Stock No: MAN00465 Rev: 1.00623