



D6 – User manual



D6 User Manual

Specifications:

Light Source:	6W COB (front) / 3W SMD (torch)
Lumens:	110/220/500 (front) / 140 (torch)
Colour temperature:	6000K
Colour Rendering Index:	CRI 95+ (front) / 90+ (torch)
Housing:	TPE rubber + ABS
Lens:	Durable PC, clear
Protection Class:	IEC III / IP65 / IK07
Battery type 1 x 18650:	3.7V – 2600mAh – 9.62Wh - Lithium rechargeable battery
Voltage:	DC5V – 1A (max)
Charging time / Active light time (hours):	4 / 7.5 & 3.5 & 2 - (front) / 5 (torch)
Operating temperature:	-20° C to +50° C
Lamp measurements:	23 x 6 x 4 cm
Lamp weight:	380 g

General Safety Instructions:

1. Do not shine in eyes.
2. Use on flat, stable surfaces.
3. Do not immerse in water or other liquids.
4. Do not operate with wet hands.
5. Do not cover.
6. Do not disassemble.
7. Do not operate if the housing, wiring or lens is open, missing or damaged.
8. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative.

Guidance for use:

Press the on/off switch on the back. Choose desired switch stage: torch – front power saving – 45% - 100% – off. Adjust the inclination of the light to the desired position up to 180 degree rotation. Use the fixed magnet on the base of the lamp or the hook on the back if desired. Lens can be replaced by turning the aluminium ring. The charging indicator (3 x LED) on back of the lamp will flash when charging is required and become full green when fully charged.

All work lights are partially charged when delivered.

1. Charge the lamp fully before use. Note: the Micro USB can only be inserted into the lamp one way.
2. Use the USB charging cable enclosed with the lamp to connect to a PC or any other suitable USB port.
3. Do not turn on when charging.
4. Do not use a modified or damaged charging cable or charger.
5. Do not leave on charge for over 24 hours.
6. Recharge every 3 months when not in use.

Cleaning:

Allow the work light to cool down sufficiently before cleaning. Clean with a dry or slightly moist, clean cloth. Do not use cleaners that contain abrasives or solvents.

Environmental Protection:

The crossed-out wheeled bin symbol indicates that waste electrical and electronic products (WEEE) should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.

